
NON-PAINTED FRAME PAINTING INSTRUCTIONS

The frame is galvanized or electro galvanized steel. Please follow the instructions below.

Step 1. Remove Weather-Strip if Installed, Before Painting

Wipe the frame clean with a solvent such as mineral spirits or acetone.

Step 2. Allow to Dry Completely

It is important to allow the frame to dry completely before proceeding to Step 3.

Step 3. Prime Coat the Frame

Use a high quality primer appropriate for the finish coat to be used. Follow the manufacturer's instructions.

Step 4. Prepare the Frame for the Finish Coat

Follow the manufacturer's instructions.

Step 5. Choose Paint Type

Use high quality acrylic water-based latex or oil-based paint for exterior installations.

Use high quality interior paint for indoor installations.

Step 6. Paint the Frame



If the frame is fire-rated, **DO NOT REMOVE THE FIRE LABEL.**

There is a transparent mask that can be removed after painting.
